

---

Author(s)	Marco Konrad
Restrictions	Public Document
Abstract	The ExpressCard standard features hot-plugging, which works differently on notebooks and desktop computers. This Application Note describes the important differences.

---

**Table of Contents**

1.0	Overview .....	1
2.0	ExpressCard Insertion and Removal in Windows .....	1
2.1	Notebooks .....	1
2.2	Desktop Computers.....	1
3.0	Contacts.....	2

---

**1.0 Overview**

ExpressCards offer a lot of advantages like higher bandwidth or short latencies in notebooks. With these enhancements the prior standard PCMCIA will be replaced more and more. Today most notebooks do not have PCMCIA slots anymore, but are already prepared for ExpressCard. Vector follows this development and uses the technological advantages of the ExpressCard standard in new products.

The ExpressCard standard features hot-plugging, but in certain cases it might not work properly. Read the following sections for details.

**2.0 ExpressCard Insertion and Removal in Windows**

**2.1 Notebooks**

The insertion and removal of ExpressCards in notebooks is possible at runtime with no restrictions. Windows 2000, XP and Vista are hot-plug capable and recognize those hardware changes at any time.

**2.2 Desktop Computers**

The hot-plug capability on desktop computers is currently restricted by the BIOS and requires ExpressCards being inserted before booting the computer. Otherwise the hardware will not be detected.

Detection is also not fully possible at runtime, if the prior detected ExpressCard is removed and plugged in again. The hardware will be deactivated in the Device Manager of Windows in this case and must be activated again manually. After an ExpressCard driver has been updated, the hardware will be deactivated, too. Reactivate the hardware in the Device Manager or reboot the system in this case.

Future BIOS versions might be able to support hot-plugging also in desktop computers.

Further technical details on this topic can be found at:

[http://download.microsoft.com/download/9/c/5/9c5b2167-8017-4bae-9fde-d599bac8184a/BIOS\\_PCl\\_e\\_HotPlug.doc](http://download.microsoft.com/download/9/c/5/9c5b2167-8017-4bae-9fde-d599bac8184a/BIOS_PCl_e_HotPlug.doc)

<http://www.microsoft.com/whdc/connect/pci/default.msp>

### 3.0 Contacts

---

**Vector Informatik GmbH**

Ingersheimer Straße 24  
70499 Stuttgart  
Germany  
Tel.: +49 711-80670-0  
Fax: +49 711-80670-111  
Email: info@vector-informatik.de

**Vector CANtech, Inc.**

39500 Orchard Hill Pl., Ste 550  
Novi, MI 48375  
USA  
Tel: +1-248-449-9290  
Fax: +1-248-449-9704  
Email: info@vector-cantech.com

**VecScan AB**

Lindholmspirén 5  
402 78 Göteborg  
Sweden  
Tel: +46 (0)31 764 76 00  
Fax: +46 (0)31 764 76 19  
Email: info@vecscan.com

**Vector France SAS**

168 Boulevard Camélinat  
92240 Malakoff  
France  
Tel: +33 (0)1 42 31 40 00  
Fax: +33 (0)1 42 31 40 09  
Email: information@vector-france.fr

**Vector Japan Co. Ltd.**

Seafort Square Center Bld. 18F  
2-3-12, Higashi-shinagawa,  
Shinagawa-ku  
J-140-0002 Tokyo  
Tel.: +81 3 5769 6970  
Fax: +81 3 5769 6975  
Email: info@vector-japan.co.jp

**Vector Korea IT Inc.**

Daerung Post Tower III, 508  
Guro-gu, Guro-dong, 182-4  
Seoul, 152-790  
Republic of Korea  
Tel.: +82-2-2028-0600  
Fax: +82-2-2028-0604  
Email: info@vector-korea.com

---